

Jotacote Universal

Product description

This is a two component polyamine cured pure epoxy coating. It is a fast drying, abrasion resistant, high solids, high build product. Designed as a universal, all round, all year, new building coating where fast dry to handle is required. Can be used as primer, mid coat, finish coat or as single coat system in atmospheric and immersed environments. Suitable for properly prepared carbon steel, galvanised steel, shop primed steel, stainless steel, aluminium and concrete substrates. It can be applied at sub zero surface temperatures.

Scope

The Application Guide offers product details and recommended practices for the use of the product.

The data and information provided are not definite requirements. They are guidelines to assist with efficient and safe use, and optimum service of the product. Adherence to the guidelines does not relieve the applicator of responsibility for ensuring that the work meets specification requirements. Jotuns liability is in accordance with general product liability rules.

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

Projects specified to the requirements in Performance Standard for Protective Coatings (PSPC)

For application and repair / maintenance requirements according to IMO MSC.215 (82) for dedicated Sea Water Ballast Tanks (WBT), and/or to IMO MSC.288 (87) for Cargo Oil Tanks of Crude Oil Tankers (COT) reference is made to the PSPC Appendix in this document.

Referred standards

Reference is generally made to ISO Standards. When using standards from other regions it is recommended to reference only one corresponding standard for the substrate being treated.

Surface preparation

The required quality of surface preparation can vary depending on the area of use, expected durability and if applicable, project specification.

When preparing new surfaces, maintaining already coated surfaces or aged coatings it is necessary to remove all contamination that can interfere with coating adhesion, and prepare a sound substrate for the subsequent product.

Inspect the surface for hydrocarbon and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area using fresh water. Paint solvents (thinners) shall not be used for general degreasing or preparation of the surface for painting due to the risk of spreading dissolved hydrocarbon contamination. Paint thinners can be used to treat small localized areas of contamination such as marks from marker pens. Use clean, white cotton cloths that are turned and replaced often. Do not bundle used solvent saturated cloths. Place used cloths into water.

Process sequence

Surface preparation and coating should normally be commenced only after all welding, degreasing, removal of sharp edges, weld spatter and treatment of welds is complete. It is important that all hot work is completed before coating commences.

Soluble salts removal

Application Guide

Jotacote Universal



Water jetting

Inspect the surface for process residues, hydrocarbon contamination and zinc corrosion by-products. If present, remove with an alkaline detergent. Agitate the surface to activate the detergent and before it dries, wash the treated area by Low-Pressure Water Cleaning (LPWC) to a grade corresponding to the description of Wa 1 (ISO 8501-4) or higher standard using fresh water.

Optimum performance is achieved with preparation to a grade corresponding to the description of Wa 2½. Minimum preparation grade is Wa 1.

Aluminium

Abrasive blast cleaning

After removal of surface defects the area to be coated shall be degreased to ISO 12944-4, Part 6.1.4 Alkaline Cleaning. The surface shall be dry abrasive brush off blast cleaned with the nozzle angle at 45-60° from perpendicular at reduced nozzle pressure to create a sharp and angular surface profile using approved non-metallic abrasive media. As a guide, a surface profile 25-55 µm, grade Fine G; Ry5 (ISO 8503-2) should be achieved. Alternatively refer to NACE no. 4/SSPC-SP7.

Smaller areas can be lightly treated with abrasive paper.

Finished surfaces shall be dull, profiled and show no areas of shiny metal.

Do not handle the prepared surface with bare hands.

Hand and Power Tool Cleaning

After removal of surface defects the area to be coated shall be degreased with an alkaline detergent, washed by Low-Pressure Water Cleaning (LPWC) to a grade corresponding to the description of Wa 1 (ISO 8501-4) or higher standard and the surface abraded using mechanical or hand sanding methods using non-metallic abrasives or bonded fibre abrasive pads to remove all polish and to impart a scratch pattern to the surface. Do not use high speed rotational sanders.

Water jetting

Inspect the surface for process residues, hydrocarbon contamination and corrosion by products. If present, remove with an alkaline detergent. Agitate the surface to activate the detergent and before it dries, wash the treated area by Low-Pressure Water Cleaning (LPWC) to a grade corresponding to the description of Wa 1 (ISO 8501-4) or higher standard using fresh water.

Stainless steel

Abrasive blast cleaning

After removal of surface defects the area to be coated shall be degreased to ISO 12944-4, Part 6.1.4 Alkaline Cleaning. The surface shall be dry abrasive brush off blast cleaned with the nozzle angle at 45-60° from perpendicular at reduced nozzle pressure to create a sharp and angular surface profile using approved non-metallic abrasive media. As a guide, a surface profile 25-55 µm, grade Fine G; Ry5 (ISO 8503-2) should be achieved. Alternatively refer to NACE no. 4/SSPC-SP7.

Hand and Power Tool Cleaning

After removal of surface defects the area to be coated shall be degreased with an alkaline detergent, washed by Low-Pressure Water Cleaning (LPWC) to a grade corresponding to the description of Wa 1 (ISO 8501-4) or higher standard and the surface abraded using mechanical or hand sanding methods using non-metallic abrasives or bonded fibre abrasive pads to remove all polish and to impart a scratch pattern to the surface. Do not use high speed rotational sanders.

Water jetting

Inspect the surface for process residues, hydrocarbon contamination and corrosion by products. If present, remove with an alkaline detergent. Agitate the surface to activate the detergent and before it dries, wash the treated area by Low-Pressure Water Cleaning (LPWC) to a grade corresponding to the description of Wa 1 (ISO 8501-4) or higher standard using fresh water.

Chlorinated or chlorine containing solvents or detergents must not be used on stainless steel.

Concrete

Application Guide

Jotacote Universal



Concrete should be a minimum of 28 days old, applying any coating before this time will greatly increase the chance of the coating de-bonding. The moisture content of the concrete should be checked prior to the application of the coating and should not be greater than 5%. Concrete substrates should be mechanically prepared to leave a clean, sound and dry base on which a coating system can be applied.

Clean – Free of oils, grease, dust, dirt, chemicals, loose coating, curing compounds, form release oils, sealers or hardeners must be removed prior to coating.

Sound – Concrete that has unsound areas (voids, hollow spots, and friable surface) may have to be removed, replaced or repaired with materials that are compatible with the selected coating system.

Dry – It is important to address dryness because most coatings require a dry surface for proper adhesion.

Moisture contained within the concrete that moves towards the surface through the pores of the concrete may prevent adequate coating adhesion.

Dry abrasive blast cleaning to SSPC-SP 13/NACE No. 6. Where the concrete has become contaminated with oils, grease, or fuels, water emulsifiable degreasers-cleaners may be used to remove these contaminants. It is important to only clean an area that can be fully washed down after degreasing before any of the cleaner can dry on the surface.

Ultra high pressure water jetting can be used to remove laitance and reveal blowholes and imperfections. Ensure concrete is dry before coating application.

Sand sweeping

Dry abrasive blast cleaning to SSPC-SP 13/NACE No. 6. All prepared surfaces should then have all "blow holes" and other surface defects filled with suitable filler that is compatible with the primer and finish coat system to ensure that the coating can be applied over a smooth and regular substrate.

Diamond disc grinding

Diamond grind the surface to remove all laitance and expose the aggregates.

Coated surfaces

Over coating

Suitable for initial surface conditions DC A, DC B and DC C prepared to surface appearance Wa 2½ (ISO8501-4). For DP I and DP Z surface appearance Wa 2 is accepted.

The maximum accepted grade of flash rust is FR L. When applied on coatings past maximum intercoating interval light abrading may be required to achieve proper intercoat adhesion.

Shop primers

Shop primers are accepted as temporary protection of steel plates and profiles. Refer to the technical data sheet for the generic types accepted. Certain standards require pre-approval of the shop primer as part of a complete system. Contact your nearest Jotun office for specific system compatibility.

Before being overcoated the shop primer must be fully cured, clean, dust free, dry and undamaged. Inorganic zinc shop primers must be free of zinc salts (white rust).

Corroded and damaged areas must be blast cleaned to minimum Sa 2½ (ISO 8501-1).

Inorganic zinc silicates

This product can be applied on top of an inorganic zinc ethyl silicate, provided the primer is cured and the product is applied using a mist-coat technique.

Application

Acceptable environmental conditions - before and during application

Before application, test the atmospheric conditions in the vicinity of the substrate for the dew formation according to ISO 8502-4.

Air temperature	-10 - 60	°C
Substrate temperature	-10 - 60	°C
Relative Humidity (RH)	10 - 85	%

Application Guide

Jotacote Universal



The following restrictions must be observed:

- Only apply the coating when the substrate temperature is at least 3 °C (5 °F) above the dew point
- Do not apply the coating if the substrate is wet or likely to become wet
- Do not apply the coating if the weather is clearly deteriorating or unfavourable for application or curing
- Do not apply the coating in high wind conditions

Product mixing

Product mixing ratio (by volume)

Jotacote Universal Comp A	3 part(s)
Jotacote Universal Comp B	1 part(s)

Induction time and Pot life

Paint temperature **23 °C**

Induction time	10 min
Pot life	1.5 h

The temperature of base and curing agent is recommended to be 18 °C or higher when the product is mixed.

Thinner/Cleaning solvent

Thinner: Jotun Thinner No. 17

Spray application

Airless Spray Equipment

Pump ratio (minimum) :	42:1
Pump output (litres/minute) :	1.3-2.2
Pressure at nozzle (minimum) :	150 bar/2100 psi
Nozzle tip (inch/1000) :	17-23
Spray angle :	40° - 80°
Filters (mesh) :	70

Several factors influence, and need to be observed to maintain the recommended pressure at the nozzle. Among factors causing pressure drop are:

- extended hoses or hose bundles
- extended hose whip-end line
- small internal diameter hoses
- high paint viscosity
- large spray nozzle size
- inadequate air capacity from compressor
- incorrect or clogged filters

Application Guide

Jotacote Universal



Film thickness per coat

Typical recommended specification range

Dry film thickness	75 - 300	µm
Wet film thickness	105 - 415	µm
Theoretical spreading rate	9,6 - 2,4	m ² /l

For DFT below 150 µm thinner should be added.

Maximum recommended film thickness is often exceeded in overlap zones and in difficult-to-spray areas.

This product can be applied up to 50 % higher than maximum specified film thickness without loss of technical properties.

Film thickness measurement

Wet film thickness (WFT) measurement and calculation

To ensure correct film thickness, it is recommended to measure the wet film thickness continuously during application using a painter's wet film comb (ISO 2808 Method 1A). The measurements should be done as soon as possible after application.

Fast drying paints may give incorrect (too low) readings resulting in excessive dry film thickness. For multi layer physically drying (resoluble) coating systems the wet film thickness comb may give too high readings resulting in too low dry film thickness of the intermediate and top coats.

Use a wet-to-dry film calculation table (available on the Jotun Web site) to calculate the required wet film thickness per coat.

Dry film thickness (DFT) measurement

When the coating has cured to hard dry state the dry film thickness can be checked to SSPC PA 2 or equivalent standard using statistical sampling to verify the actual dry film thickness. Measurement and control of the WFT and DFT on welds is done by measuring adjacent to and no further than 15 cm from the weld.

Ventilation

When coatings are applied in a confined space, its solvent will evaporate and produce an explosive atmosphere unless solvent concentration is immediately reduced to a non-explosive level, therefore artificial ventilation is required. During application it is recommended to provide enough ventilation to have a safe work environment and to ensure that solvent concentration in the tank at no time exceeds the maximum permitted according to local health and safety regulations.

After application it is recommended to increase the ventilation (see later in this document) as long as solvent is released from the uncured film. This is usually 10% of the product's Lower Explosive Limit.

As a guideline for good ventilation, after application the confined space should be ventilated with 3-5 cycles per hour for 12 hours and can be reduced to 1 cycle per hour until coating is fully cured.

As solvent is heavier than air and will tend to accumulate in the lower areas of tanks, ventilation system and trunking must be arranged to efficiently remove solvent vapour from these areas.

The extraction hose should be close to the bottom of the tank (approximately 50~100 cm above the tank top). Ventilation air (input) should be organised in a way so all parts of the tank are well circulated.

Stripe coating

Application Guide

Jotacote Universal



The stripe coat sequence can be either of the following:

1. Surface preparation, stripe coat, full coat.
2. Surface preparation, full coat, stripe coat. This sequence can be used when a large substrate area has been prepared and leaving the substrate exposed for a long time while doing stripe coating could lead to surface deterioration.

It is important to pay special attention to edges, openings, rear sides of stiffeners, scallops etc. and to apply a stripe coat to these areas where the spray fan may not reach or deposit an even film.

When applying a stripe coat to bare metal use only a stiff, round stripe coating brush to ensure surface wetting and filling of pits in the surface.

Stripe coating shall be of a different colour to the main primer coat and the topcoat colour and should be applied in an even film thickness, avoiding excessive brush marks in order to avoid entrapped air. Care should be taken to avoid excessive film thickness. Pay additional attention to pot life during application of stripe coats.

Jotun recommends a minimum of one stripe coat. However, in extremely aggressive exposure conditions there may be good reason to specify two stripe coats.

Drying process

Do not attempt to speed up the curing process by blowing hot air on to the wet coating film as this may lead to skin drying/curing, entrapped solvents and consequently solvent blistering and inferior corrosion protection.

Coating loss

The consumption of paint should be controlled carefully, with thorough planning and a practical approach to reducing loss. Application of liquid coatings will result in some material loss. Understanding the ways that coating can be lost during the application process, and making appropriate changes, can help reducing material loss.

Some of the factors that can influence the loss of coating material are:

- type of spray gun/unit used
- air pressure used for airless pump or for atomization
- orifice size of the spray tip or nozzle
- fan width of the spray tip or nozzle
- the amount of thinner added
- the distance between spray gun and substrate
- the profile or surface roughness of the substrate. Higher profiles will lead to a higher "dead volume"
- the shape of the substrate target
- environmental conditions such as wind and air temperature

Drying and Curing time

Substrate temperature	-10 °C	-5 °C	0 °C	5 °C	10 °C	23 °C	40 °C
Surface (touch) dry	36 h	20 h	14 h	8 h	5 h	2.5 h	1 h
Walk-on-dry	4 d	48 h	30 h	16 h	10 h	5 h	2 h
Dry to over coat, minimum	42 h	24 h	18 h	10 h	7 h	4 h	2 h
Dried/cured for service			21 d	14 d	10 d	7 d	3 d
Dried/cured for immersion	10 d	7 d	4 d	3 d	2 d	1 d	12 h

Drying and curing times are determined under controlled temperatures and relative humidity below 85 %, and at average of the DFT range for the product.

Surface (touch) dry: The state of drying when slight pressure with a finger does not leave an imprint or reveal tackiness.

Walk-on-dry: Minimum time before the coating can tolerate normal foot traffic without permanent marks, imprints or other physical damage.

Dry to over coat, minimum: The shortest time allowed before the next coat can be applied.

Dried/cured for service: Minimum time before the coating can be permanently exposed to the intended environment/medium.

Dried/cured for immersion: Minimum time before the coating can be permanently immersed in sea water.

Maximum over coating intervals

Maximum time before thorough surface preparation is required. The surface must be clean and dry and suitable for over coating. Inspect the surface for chalking and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by low-pressure water jetting to Wa 1 (ISO 8501-4) using fresh water.

If maximum over coating interval is exceeded the surface should in addition be carefully roughened to ensure good inter coat adhesion.

For surface preparation reference is made to the recommendations for coated surfaces.

The referred intervals relate specifically to over coating with Jotun Performance Coating products.

Areas for atmospheric exposure

Average temperature during drying/curing	-10 °C	-5 °C	0 °C	5 °C	10 °C	23 °C	40 °C
Itself	5 mth	3 mth	3 mth	3 mth	3 mth	3 mth	2 mth
acrylic	1 mth	14 d	10 d	7 d	7 d	5 d	1 d
alkyd			10 d	5 d	5 d	3 d	1 d
epoxy	5 mth	3 mth	3 mth	3 mth	3 mth	3 mth	2 mth
epoxy Passive Fire Protection				14 d	14 d	14 d	7 d
polysiloxane			20 d	20 d	20 d	14 d	10 d
polyurethane			20 d	20 d	20 d	14 d	10 d
vinyl epoxy	2 mth	1.5 mth	1 mth	1 mth	1 mth	1 mth	20 d

Areas for immersed exposure

Average temperature during drying/curing	-10 °C	-5 °C	0 °C	5 °C	10 °C	23 °C	40 °C
Itself	14 d	14 d	14 d	14 d	14 d	14 d	10 d
epoxy	14 d	14 d	14 d	14 d	14 d	14 d	10 d
vinyl epoxy	14 d	14 d	14 d	14 d	14 d	14 d	10 d

Other conditions that can affect drying / curing / over coating

Adding anti-skid to the coating system

Anti skid aggregate should only be added in the final coat, and should not be used in single coat systems. Spread the aggregate evenly on the surface before half of time to Surface dry. Use Jotun Anti-skid, medium particle size (400 - 600 µm) for coatings applied in 150 to 400 µm DFT. The recommended usage is 2.5 - 3.3 kg per 10 litres of paint.

Repair of coating system

Application Guide

Jotacote Universal



General comment for Water ballast tank coatings:

Minor coating damage may be prepared to St 3 (ISO 8501-1:2007) with minimum 25 microns surface profile equivalent to SSPC SP11. This method of preparation is only recommended for small damages where abrasive blasting would make excessive damage to surrounding coatings. Edges of intact surrounding coating should be feathered so the consecutive layers of coating are exposed; a thorough vacuum cleaning of the area should be carried out before paint application take place.

Detailed background information about ventilation arrangements and calculations is given in the Code of Practice for Tank Coating, available at jotun.com. A "Ventilation calculator" that can be used for different coatings and thinners is also available at jotun.com.

Damages to the coating layers:

Prepare the area through sandpapering or grinding, followed by thorough cleaning/vacuuming. When the surface is clean and dry the coating may be over coated by itself or by another product, ref. original specification.

Always observe the maximum over coating intervals. If the maximum over coating interval is exceeded the surface should be carefully roughened in order to ensure good intercoat adhesion.

Damages exposing bare substrate:

Remove all rust, loose paint, grease or other contaminants by spot blasting, mechanical grinding, water and/or solvent washing. Feather edges and roughen the overlap zone of surrounding intact coating. Apply the coating system specified for repair. Damage in the surface of the coating or of size less than 5 cm² can be repaired by roughening of the surface by abrasive sanding or equal.

Damage to the coating that exposes bare steel where the damaged area is less than 5 cm² should be mechanically cleaned by abrasive sanding to a minimum standard of St 3 with a rough surface profile. Damage to the coating that exposes bare steel where the damaged area is greater than 5 cm² shall be dry abrasive blast cleaned to Sa 2½ (ISO 8501-1), preferably by the use of vacuum blasting equipment. Coating damage that exceeds 0.5% of the total area should be removed and replaced. All noted defects should be repainted to conform to the coating specification.

Overlapping zones to intact coating shall be masked off with a minimum 200 mm distance to the damage and should cover the surrounding area so that overspray to sound coating does not occur during repair application. Edges of intact coating around damage shall be feathered to ensure a smooth transition from the coating to the prepared steel. Consecutive layers of coating shall be feathered to expose each layer and new coating shall always overlap to an abraded existing layer.

Areas with too low DFT:

Roughen the surface, vacuum and apply new coating according to specification.

Areas with too high DFT:

Areas with with DFT above maximum specified for isolated areas shall be ground down to acceptable thickness, or down to bare steel and recoated.

Repair of damaged areas

Sags and runs can be caused by too high wet film thickness, too much thinner added or the spray gun used too close to the surface.

Repair by using a paint brush to smooth the film when still wet.

Sand down to a rough, even surface and re-coat if the coating is cured.

Orange peel can be caused by poor flow/levelling properties of the paint, poor atomization of the paint, thinner evaporating too fast or the spray gun held too close to the surface.

This can be rectified by abrading the surface and applying an additional coat after having adjusted the application properties or the application technique.

Dry spray can be caused by poor atomization of the paint, spray gun held too far from the surface, high air temperature, thinner evaporating too fast or coating applied in windy conditions.

Sand down to a rough even surface and re-coat.

Pinholes can be caused by entrapped solvents in the film or by incorrect application technique. Pinholes can be repaired as per procedure for damages to the coating layer or to the substrate, ref. above.

Coating film continuity

Jotun recommends that all tank coating systems are pinhole/defect tested either by ASTM D 5162, test methods A or B as appropriate for the actual dry film thickness after cured for service.

In general test method A (Low voltage wet sponge) is recommended for dry film thickness up to 500 µm using 90 Volts. For higher film thickness test method B (High voltage spark test) is recommended using 400 Volts per 100 µm.

Alternatively by visual observation of pin hole rusting after water immersion. For water immersion test use of seawater is recommended. Immersion time should be at least 24 hours. If fresh water is used the immersion time should be at least 48 hours.

All noted defects shall be repaired using best practical means and methods.

Performance Standard for Protective Coatings (PSPC)

PSPC Appendix (WBT)

Application requirements particular for coating according to Performance Standard for Protective Coatings (PSPC) of dedicated seawater ballast tanks to IMO Resolution MSC.215 (82)

Job specification

There shall be a minimum of two stripe coats and two spray coats, except that the second stripe coat, by way of welded seams only, may be reduced in scope where it is proven that the NDFT (nominal total dry film thickness) can be met by the coats applied in order to avoid unnecessary over thickness. Any reduction in scope of the second stripe coat shall be fully detailed in the CTF.

NDFT (nominal total dry film thickness)

NDFT 320 µm with 90/10 rule. (Minimum 90 % of all DFT measurements shall be greater than or equal to the NDFT and none of the remaining 10 % measurements shall be below 0.9 x NDFT).

Maximum DFT 2000 µm is acceptable for isolated spots only, and should not extend to more than 1 % of the total tank area.

PRIMARY SURFACE PREPARATION

Blasting and surface profile:

Cleanliness minimum Sa 2½ (ISO 8501-1)
Surface profile 30-75 µm (ISO 8503-2)

Blasting shall not be carried out when:

- the relative humidity is above 85 %
- the surface temperature of steel is less than 3 °C above the dew point

Water soluble salts limit equivalent to NaCl

Maximum 50 mg/m² of sodium chloride (ISO 8502-6/9)

SECONDARY SURFACE PREPARATION

Steel condition

For steel preparation, PSPC makes reference to grade P2 (ISO 8501-3). All sharp edges are to be rounded to a radius of minimum 2 mm, subject to a three-pass grinding, or treated with an alternative process giving an edge profile that results in a dry film thickness retention corresponding to or better than a three pass grinding. Sharp edges mean all edges except natural rounded/rolled edges of sections.

Surface treatment

Cleanliness minimum Sa 2½ (ISO 8501-1) on damaged shop primer and welds.

Surface treatment after erection

Water ballast tanks (WBT), IMO Resolution MSC.215 (82)

Erection joints minimum St 3 or Sa 2½ (ISO 8501-1) where practicable.

- Damages up to 2 % of the area to be coated to be treated to minimum St 3
- Contiguous damages over 25 m² or over 2 % of the area to be coated, Sa 2½ shall be applied
- Coating in overlap shall be feathered

Profile requirements

In case of full or partial blasting surface profile 30-75 µm (ISO 8503-2).

Dust

Dust quantity rating 1 for dust size class 3 or larger (ISO 8202-3).

Lower dust size classes to be removed if visible without magnification on the surface to be coated.

Water soluble salts limit equivalent to NaCl after blasting/ grinding

Application Guide

Jotacote Universal



Maximum 50 mg/m² of sodium chloride (ISO 8502-6/9).

Contamination

No oil contamination.

Inspect the surface for contaminations and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by Low-Pressure Water Cleaning (LPWC) to Wa 1 (ISO 8501-4) using fresh water.

Ventilation

Sufficient ventilation must be provided to remove the solvent evaporating from the coating. When mixed, this product requires exchange of 56 m³ air per litre paint in order to dilute the evaporating solvent to a safe concentration in the tank (i.e. less than 10 % of the Lower Explosion Limit, LEL). The solvent gas concentration in the tank must at all times be kept below this level, hence sufficient ventilation must be maintained during the whole application and drying periods.

Environmental conditions

Coating shall be applied under controlled humidity and surface conditions, in accordance with the manufacturer's specifications. In addition, coating shall not be applied when:

- the relative humidity is above 85 %
- the surface temperature is less than 3 °C above the dew point
- the surface is wet or is likely to become wet

Testing of coating

Destructive testing should be avoided.

Dry film thickness shall be measured after each coat for quality control purposes. The total dry film thickness shall be documented after completion of the final coat, using appropriate thickness gauges.

Repair and maintenance procedures relevant to coating according to Performance Standard for Protective Coatings (PSPC) of dedicated seawater ballast tanks to IMO Resolution MSC.215(82)

Superficial damages not exposing bare substrate:

Prepare the area through sandpapering or grinding, followed by thorough cleaning/vacuuming. When the surface is dry and clean the coating may be over coated by itself or by another product, ref. original specification. Always observe the minimum and maximum over coating intervals. If the maximum over coating interval is exceeded the surface should be carefully roughened in order to ensure good intercoat adhesion.

Damages exposing bare substrate:

Choice of surface preparation and application methods shall be made in conjunction with Jotun and the actual Classification Society, following the guidelines in:

MSC.1/Circ. 1330 (WBT)

- Chapter 4.1 for coating condition assessment
- Chapter 5 for coating maintenance
- Chapter 6 for coating repair

Quality assurance

The following information is the minimum required. The specification may have additional requirements.

- Confirm that all welding and other metal work has been completed before commencing pre-treatment and surface preparation
- Confirm that installed ventilation is balanced and has the capacity to deliver and maintain the RAQ
- Confirm that the required surface preparation standard has been achieved and is held prior to coating application
- Confirm that the climatic conditions are within recommendations in the AG, and are held during the application
- Confirm that the required number of stripe coats have been applied
- Confirm that each coat meets the DFT requirements in the specification
- Confirm that the coating has not been adversely affected by rain or other factors during curing
- Observe that adequate coverage has been achieved on corners, crevices, edges and surfaces where the spray gun cannot be positioned so that its spray impinges on the surface at 90° angle
- Observe that the coating is free from defects, discontinuities, insects, abrasive media and other contamination
- Observe that the coating is free from misses, sags, runs, wrinkles, fat edges, mud cracking, blistering, obvious

Application Guide

Jotacote Universal



pinholes, excessive dry spray, heavy brush marks and excessive film build
- Observe that the uniformity and colour are satisfactory

All noted defects shall be fully repaired to conform to the coating specification.

Caution

This product is for professional use only. The applicators and operators shall be trained, experienced and have the capability and equipment to mix/stir and apply the coatings correctly and according to Jotun's technical documentation. Applicators and operators shall use appropriate personal protection equipment when using this product. This guideline is given based on the current knowledge of the product. Any suggested deviation to suit the site conditions shall be forwarded to the responsible Jotun representative for approval before commencing the work.

For further advice please contact your local Jotun office.

Health and safety

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not inhale spray mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

Accuracy of information

Always refer to and use the current (last issued) version of the TDS, SDS and if available, the AG for this product. Always refer to and use the current (last issued) version of all International and Local Authority Standards referred to in the TDS, AG & SDS for this product.

Colour variation

Some coatings used as the final coat may fade and chalk in time when exposed to sunlight and weathering effects. Coatings designed for high temperature service can undergo colour changes without affecting performance. Some slight colour variation can occur from batch to batch. When long term colour and gloss retention is required, please seek advice from your local Jotun office for assistance in selection of the most suitable top coat for the exposure conditions and durability requirements.

Reference to related documents

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

When applicable, refer to the separate application procedure for Jotun products that are approved to classification societies such as PSPC, IMO etc.

Symbols and abbreviations

min = minutes

h = hours

d = days

°C = degree Celsius

° = unit of angle

µm = microns = micrometres

g/l = grams per litre

g/kg = grams per kilogram

m²/l = square metres per litre

mg/m² = milligrams per square metre

psi = unit of pressure, pounds/inch²

Bar = unit of pressure

RH = Relative humidity (% RH)

UV = Ultraviolet

DFT = dry film thickness

WFT = wet film thickness

TDS = Technical Data Sheet

AG = Application Guide

SDS = Safety Data Sheet

VOC = Volatile Organic Compound

MCI = Jotun Multi Colour Industry (tinted colour)

RAQ = Required air quantity

PPE = Personal Protective Equipment

EU = European Union

UK = United Kingdom

EPA = Environmental Protection Agency

ISO = International Standards Organisation

ASTM = American Society of Testing and Materials

AS/NZS = Australian/New Zealand Standards

NACE = National Association of Corrosion Engineers

SSPC = The Society for Protective Coatings

PSPC = Performance Standard for Protective Coatings

IMO = International Maritime Organization

Application Guide

Jotacote Universal



Disclaimer

The information in this document is given to the best of Jotun's knowledge, based on laboratory testing and practical experience. Jotun's products are considered as semi-finished goods and as such, products are often used under conditions beyond Jotun's control. Jotun cannot guarantee anything but the quality of the product itself. Minor product variations may be implemented in order to comply with local requirements. Jotun reserves the right to change the given data without further notice.

Users should always consult Jotun for specific guidance on the general suitability of this product for their needs and specific application practices.

If there is any inconsistency between different language issues of this document, the English (United Kingdom) version will prevail.
